



HAVIT  OWS907 OPEN-EAR WIRELESS HEADPHONES USER MANUAL	Product and accessories  Earbud *2  Charging case *1  Type-C Charging cable *1  User manual *1  Certificate of quality *1 1	Production structure  1. Multifunction button (MFB) 2. Earbuds indicator 3. Charging port 4. Power LED indicator Wearing method Gently insert the earbuds into the ear then adjust the appropriate comfort.  2	Basic function Power on, Bluetooth connection -Follow the steps (Please confirm that your phone is built-in Bluetooth function) 1.Power on Method 1: Take out the earbuds from the charging case. Method 2: Long press the MFB for 3s. The earbuds enter the pairing mode automatically while the earbud indicator of one earbud flashes. 2. Turn on Bluetooth on your device and select "HAVIT OWS907" referring to your phone instructions. Pairing mode can just last 5 minutes. If you miss the pairing time, you need to restart the device and operate follow the procedural steps mentioned above. *Note: a).HAVIT OWS907 remembers previously connected devices. When turned on, the earbuds attempts to reconnect to previously connected devices. b).HAVIT OWS907 will disconnect when deviate the working range of Bluetooth. The earbuds will reconnect automatically if you come back to the range in 5 minutes. 3	Power off Method 1: Put the earbuds into the charging case, they will automatically shut off. Method 2: Long press the MFB for 5s. Answer incoming calls Double press the left or right MFB. End the call Double press the left or right MFB. Decline incoming call Long press the left or right MFB for 1s. One key for voice assistant Both earbuds work: Triple press the left MFB. Single earbud work: Triple press the MFB of working earbud. Switch on/Switch off Game mode Triple tap the right MFB to switch on Game Mode / Music Mode. Music playing 1. Play/Pause: Double press the left or right MFB. 2. Previous song: Long press the left MFB 4
for 1s. 3. Next song: Long press the right MFB for 1s. Charging -Case Charge the case using the Type-C cable connected to a computer or wall charger. 0-33%, the power LED indicator flashes yellow and the white and blue indicator turns off until next status. 33%-66%, the power LED indicator flashes white, the yellow indicator is always on and the blue indicator turns off until next status. 66%-100%, the power LED indicator flashes blue and the yellow and white indicator is always on until next status. Full charged, all the power LED indicator is always on. Mono mode (Take out any earbuds as a unilateral Bluetooth earbud.) (Note: Single channel mode only needs to remove one of earbuds from the charging case, if two earbuds are removed before connection, the earbud will be used in TWS mode by default, and the TWS connection will be automatically realized.) 1. Take out one earbud from charge case, the 5	earbuds automatically turn on and reconnect to previous connected devices. 2. Switch from one earbud to the other earbud when playing music, taking out the other earbud from the charging case and these two earbuds will connected automatically. Both earbuds will play music automatically and then put the earbud which do not need anymore into the charging case and the switching process completes. (Note: Call mode is applicable.) 3. Please refer to the TWS mode for more functions. Restore factory settings If the earbuds can't pair frequently, please restore the factory settings. Press the left and right MFB at the same time for four times, while the earbuds indicator flashes for 1s, the earbuds will enter the pairing mode again, search the "HAVIT OWS907" Bluetooth pairing name with the mobile phone and connect again. Specification Bluetooth Version: V5.3 Wireless Working Range: 10M(Without obstacles) Earbuds Battery: 30mAh 6	Charging Case Battery:250mAh Play Time: about 6h (60%Vol.) Talk Time: about 3.5h Case Charging Time: about 2h Speaker Size: φ13mm*2 Speaker Frequency: 20Hz~20kHz Input Voltage/Current: DC 5V/0.3A USB Port: Type-C Warnings 1. Please follow the instruction to operate. 2. Please charge the earbuds with input power below 5V/1A, in order to protect the battery. 3. Please store or use the earbuds in a normal temperature environment. 4. Please do not use this product near the water. Do not immerse this product in any liquid or splash any liquid on this product. 5. Please keep the earbuds from heat source, such as radiators, hot air regulators,stoves,or other heat generating instruments. As it is not anti high temperature. 6. Don't jam the ports of the earbuds, such as charger port, LED port and microphone etc.. 7. In order to protect your hearing and extend the speaker service life, it is not recommended to adjust the volume to the 7	maximum level for a long time. 8. Whatever reasons damage the earbuds, please feel free to contact our after-sales staff in time rather than repair by yourself. Otherwise, you will accept without after-sales service. 8	 www.havitsmart.com 9